



28g Nano-Cube

CABINET STAND



ASSEMBLY INSTRUCTIONS

Transworld Aquatic Enterprises, Inc

3730 W. Century Blvd #3
Inglewood, CA 90303
Phone: (877) 374-9981

Rev. 102214

JBJLIGHTING.COM

TABLE OF CONTENTS	
Parts	4-7
Step 1 Mounting Hinges	8
Step 2 Mounting Chiller Vents	8
Step 3 Left Side Panel to Back Panel	9
Step 4 Right Side Panel to Back Panel	9
Step 5 Feet to Bottom Panel	10
Step 6 Bottom Panel to Side Panels	10
Step 7 Top Mid Panel to Cabinet	11
Step 8 Aluminum Riser	12
Step 9 Top Panel to Aluminum Riser	13
Step 10 Door To Cabinet	14
Step 11 Door Knob to Door	14


STEP 10**Door to Cabinet***8—1/2" Screws & Door with Mounted Hinges*

- Line up pre-drilled holes on right side panel for the hinges
- Screw in hinges on the door to the right side panel

STEP 11**Door Knob to Door***Door Knob Screw & Door Knob*

- Feed Door Knob Screw through inside of Door
- Attach Door Knob to Door by tightening Door Knob to Door Knob Screw

PARTS EXPLODED VIEW & IDENTIFICATION




STEP 9


Top Panel to Aluminum Riser

*4 Thick Mounting Screws from Aluminum Riser Assembly
Locate 4 Recessed Holes on Top Panel—This side is the top.*

- Feed 4 Thick Mounting Screws through Recessed Holes on Top Panel (Screws will pop through the veneer)
- Screw Top Mounting Plate to Thick Screws (Center Hole). *Do not Tighten—only a few turns to attach.*
- Align Top Panel with Screws to Center Holes on Aluminum Risers & Tighten Screws



STEP 8 Aluminum Riser



Take apart Chrome Cylinder Assembly.


Remove Hex Screw from Bottom Mounting Plate.

1—Attach Bottom Mounting Plate from Chrome Cylinder to Top Mid Panel.

2—Line up 2 holes to Bottom Mounting Plate—insert 1/2" screws and tighten.

3—Insert Hex screw into center of Bottom Mounting Plate—Hand Tighten..


4— Screw Chrome Cylinder to hex screw. Tighten by hand. DO NOT over tighten.



#	Name
1	LEFT SIDE PANEL
2	BACK PANEL W/ CHILLER VENT
3	RIGHT SIDE PANEL
4	MID TOP PANEL
5	BOTTOM PANEL
6	TOP PANEL
7	CABINET DOOR
8	SHELF
9	RIGHT DOOR
10	SHELF

Please confirm all panels are included inside box.
Any scratched or dents should be reported to the manufacturer before assembly.
Please contact JBJ-USA
877-374-9981
warranty@jbjlighting.com

HARDWARE INCLUDED



DOOR HINGE (2)



CAMLOCKS(18)



CAMLOCKS SCREWS (18)



1/2" SCREWS (28)



1/2" ROUNDED HEAD SCREWS (11)



DOOR KNOB SCREW




CABINET DOOR KNOB

**STEP 7
Top Mid Panel to Cabinet**

*6 Camlocks & 6 Camlock Screws
Locate Top-Mid Panel. There are 4 small pilot holes on top side and 6 Camlock Mounting Holes on Bottom Side*

- Insert 6-Camlock Screws to Under side of Top-Mid Panel
- Insert 2 Camlocks to Left Side Panel
- Insert 2 Camlocks to Back Panel
- Insert 2 Camlocks to Right Side Panel
- Attach Top Mid Panel to Cabinet
- Secure Top-Mid Panel to Cabinet by tightening Camlocks




NOTE: Make Sure Pilot holes on Top Mid Panel are facing top for Aluminum Risers

STEP 5**Plastic Feet Legs to Bottom Panel**

4-1" Screws & 4 Plastic Feet

- Locate Bottom Panel—Has 4 holes for feet mounting
- Feed 1" Screw through Plastic Feet
- Mount Feet aligning screws to holes on Bottom Panel

**STEP 6****Bottom Panel to Back and Side Panels**

6-Camlocks & 8 Camlock Screws

- Insert 6 Camlock Screws to Bottom Panel
- Insert 2 Camlocks to Right Side Panel
- Insert 2 Camlocks to Left Side Panel
- Insert 2 Camlocks to Back Panel
- Attach Bottom Panel to Cabinet
- Secure Bottom Panel to Cabinet by tightening Camlock Screws

SEE ABOVE PIC



ALUMINUM RISERS W/ SCREWS (4)



SHELF HOLDERS (4)



PLASTIC CABINET FEET (4)




1" CABINET FEET SCREWS (4)

Please confirm all hardware pieces are included inside box.

Please contact JBJ-USA
877-374-9981
warranty@bjlighting.com


STEP 1 Mounting Hinges to Door

8—1/2" Screws
Mount Hinges on Door




STEP 2 Mounting Chiller Vents to Left & Right Side

- 2 Chiller Vents & 8 1/2" Rounded Head Screws
- Insert Chiller Vent into Size Left and Right Side Panels
 - Use 1/2" Rounded Head Screws through holes on Chiller Vents



STEP 3 Left Side Panel to Back Panel

- Insert 2 Camlock Screws to Left Side Panel
- Insert 2 Camlock to Back Panel
- Attach Left Side Panel to Back Panel & Front Support Bracket
- Secure by tightening Camlocks



STEP 4 Right Side Panel to Back Panel

- 2 Camlock & Camlock Screws
- Insert 2 CamLocks Screws to Right Side Panel
 - Insert 2 Camlock to Back Panel
 - Attach Right Side Panel to Back Panel
 - Secure Right Side Panel to Back Panel by tightening Camlocks

